

# VERY IMPORTANT: UPDATED JUMPER SETTINGS AS OF 3/13/03

10

## Jumper Settings

**KEY: Open**  **Closed** 

**CLOSED:** In a closed setting the jumper is attached to both pins.

**OPEN:** An open setting will have either no jumper or the jumper will be attached to only one pin.

SYSTEM BUS MULTIPLIER

JUMPER SETTINGS					
	J1	J2	J3	J4	J5
6x	⋮	▬	▬	⋮	▬
6.5x	⋮	⋮	▬	⋮	▬
7	⋮	⋮	⋮	▬	⋮
7.5x	⋮	⋮	⋮	⋮	▬
8x	⋮	▬	▬	⋮	⋮
9x	▬	⋮	▬	▬	▬
10x	▬	▬	⋮	▬	⋮
11x	▬	▬	⋮	⋮	▬
12x	▬	▬	⋮	▬	▬
13x	▬	⋮	▬	⋮	▬
14x	▬	▬	▬	⋮	⋮
15x	▬	⋮	⋮	⋮	▬
16x	▬	▬	▬	⋮	▬

CPU SPEED	
100 MHz Bus Models AGP (Sawtooth) Mac Server G4 Gigabit Ethernet	133 MHz Bus Models Digital Audio Quicksilver Quicksilver 2002
600 MHz	800 MHz
650 MHz	867 MHz
700 MHz	933 MHz
750 MHz	1 GHz
800 MHz	1.067 GHz
900 MHz	1.2 GHz
1 GHz	1.33 GHz
1.1 GHz	1.467 GHz
1.2 GHz	1.6 GHz
1.3 GHz	1.73 GHz
1.4 GHz	1.86 GHz
1.5 GHz	2.0 GHz
1.6 GHz	2.13 GHz

Additional settings supported by G-Celerator models with a GC5A or GC7 prefix:

NOTE: These settings are new and CPU speed will not be correctly identified by Profiler.

8.5x	⋮	⋮	▬	▬	⋮
9.5x	⋮	⋮	▬	▬	▬
10.5x	▬	▬	⋮	⋮	⋮
11.5x	⋮	⋮	⋮	⋮	⋮
12.5x	▬	▬	▬	▬	▬
13.5x	⋮	▬	▬	▬	⋮

850 MHz	1.13 GHz
950 MHz	1.26 GHz
1.05 GHz	1.4 GHz
1.15 GHz	1.53 GHz
1.25 GHz	1.66 GHz
1.35 GHz	1.8 GHz