




MERCURY ACCELSIOR® E2



PACKAGE CONTENTS

- OWC Mercury Accelsior® E2 PCIe card
- 2 Mercury Accelsior SSD blades *
- Quick Start Guide
- * Blades not included on 0GB model.

SYSTEM REQUIREMENTS & INSTALLATION

APPLE MAC REQUIREMENTS

OS: Mac OS X 10.6.8 or later

HARDWARE: Intel Mac Pro with an available PCIe 2.0 or 1.0 slot capable of supporting a x2 PCIe card. For optimal performance, use a PCIe 2.0 slot running at x4 speeds or greater.

PC REQUIREMENTS

OS: Windows® Vista and later

HARDWARE: PC with an available PCIe 2.0 or 1.0 slot capable of supporting x2 PCIe cards. For optimal performance, use a PCIe 2.0 slot running at x4 speeds or greater.

HARDWARE INSTALLATION

Before Installing the Mercury Accelsior E2 PCIe SSD:

- Make sure computer is turned off and unplugged from its power source.
- Take appropriate electrostatic discharge precautions:



Your computer is a static-sensitive device. It is susceptible to invisible damage if not protected during installation.

We recommend proper grounding by using a grounding strap. Make sure to work in a clean, static-free area, and avoid wearing clothing that retains static charges.

- STEP 1:** Open the computer's chassis and locate an unused PCIe 2.0 or 1.0 slot (x4, x8, or x16 slot required). For optimal performance, use a PCIe 2.0 slot running at x4 speeds or greater.
- STEP 2:** Remove the PCIe slot cover.
- STEP 3:** Gently insert the Mercury Accelsior E2 card into the PCIe slot and secure the bracket to the computer chassis according to your chassis specifications.
- STEP 4:** After installing the Mercury Accelsior E2 card, start your computer.
- STEP 5:** Insert your preferred operating system install disc and proceed to install the system as you normally would.

QUICK START GUIDE



WARRANTY INFORMATION

Warranty information for the Mercury Accelsior E2 PCIe SSD can be found at: www.owcdigital.com/terms/

TECHNICAL SUPPORT

HOURS OF OPERATION

8AM - 8PM (CT) Monday - Friday
9AM - 4PM (CT) Saturday



(866) 692-7100 (North America)
+1 (815) 338-4751 (International)



Live Chat is available during normal business hours at: www.owcdigital.com/support



Email Support is available at: www.owcdigital.com/support

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of OWC.

© 2016 OWC. All rights reserved.

OWC and Mercury Accelsior are trademarks of New Concepts Development Corporation, registered in the U.S. Patent and Trademark Office and/or in Canada. The OWC logo is a trademark of New Concepts Development Corporation. Apple, Mac, Mac Pro, and OS X are trademarks of Apple Inc., registered in the United States and other countries. Windows is a registered trademark of Microsoft Corporation in the United States and other countries. Other marks may be the trademark or registered trademark property of their owners.